

## FORZA COPPER "V" PRESS DN50 INSTALLATION INSTRUCTIONS

The following instructions explain the correct installation procedure for 50mm FORZA Copper "V" Press fittings with a 50mm support sleeve.

1



Cut copper at 90° and deburr both internally and externally.

2



Insert 50mm support sleeve into copper tube.

3



Insert tube with support sleeve into 50mm fitting. 50mm fitting is now ready to be pressed.